

POLYREY
Usine de Couze
24150 LALINDE
Frankreich

Burgdorf, 02.02.2021

Test order No. 2021-0121

Date of order: 21.01.2021
Responsible:
Pages: 2

Method:

JIS Z 2801 Quantitative analysis for determination of the
bacteriostatic activity; film 35x35mm; inoculum 120ul:

SANITIZED AG



Erich Rohrbach
Head Microbiology

The findings are valid for the tested object(s) only. Filing record of report and documentation is 10 years.

Results

Description of sample

Sample number: **2021-0121-03** Received: 21.01.2021
Business: POLYMER Type: QC

Identification: B010 Blanc megeve 521314
Main Component: 65% Decorative paper
Minor Component: 35% Thermosetting resin
Appearance: White
Field of Application: Cabine line – furniture and interior fitting

Sanitized Products: Sanitized® BC A 21-61
Declared quantity: -
Finishing Process(es): Treating

Remark: Production sample
Incubation time: 24 hours
White coated side tested

Test results of the SANITIZED-laboratory

Quantitative analysis for determination of the bacteriostatic activity:				
Method	Test point	Activity	Reduction in %	Evaluation
JIS Z 2801	Staphylococcus aureus ATCC 6538P	>4.50	>99.99	Good effect

EGY STONE



POLYREY
Usine de Couze
24150 LALINDE
Frankreich

Burgdorf, 01.03.2018

Test order No. 2018-0189

Date of order: 16.02.2018
Responsible:
Pages: 2

Method:

JIS Z 2801:2010 Quantitative analysis for determination of the
bacteriostatic activity; film 35x35mm; inoculum 120ul:

SANITIZED AG

A blue ink signature of Erich Rohrbach, written in a cursive style.

Erich Rohrbach
Head Microbiology

The findings are valid for the tested object(s) only. Filing record of report and documentation is 10 years.

Results

Description of sample

Sample number: **2018-0189-01**
Business: **POLYMER**

Received: 16.02.2018
Type: QC

Identification: 417500374
Main Component: 65% Decorative paper
Minor Component: 35% Thermosetting resins
Appearance: Bouleau de Sibirie
Field of Application: Cabine line - furniture & interior

Sanitized Products: Sanitized® BC A 21-61
Declared quantity: -

Remark: Production sample

Test results of the SANITIZED-laboratory

Quantitative analysis for determination of the bacteriostatic activity:				
Method	Test point	Activity	Reduction in %	Evaluation
JIS Z 2801:2010	Escherichia coli ATCC 8739	>4.50	>99.99	Good effect
JIS Z 2801:2010	Klebsiella pneumoniae ATCC 4352	>4.70	>99.99	Good effect
JIS Z 2801:2010	Listeria monocytogenes ATCC 15313	>3.80	>99.98	Good effect
JIS Z 2801:2010	Staphylococcus aureus (MRSA) ATCC 33592	>4.70	>99.99	Good effect
JIS Z 2801:2010	Pseudomonas aeruginosa ATCC 15442	>4.90	>99.99	Good effect
JIS Z 2801:2010	Salmonella enteritidis ATCC 13076	>4.20	>99.99	Good effect
JIS Z 2801:2010	Staphylococcus aureus ATCC 6538P	>4.30	>99.99	Good effect